
### **ADJUSTABLE HOLDER**


ADJUSTABLE HOLDER is a holder for attaching protective shield (glass/acrylic) to the table. The size of the table and the glass used can vary because the glass and the holder are not permanently attached. So that the glass can be replaced as needed with a maximum thickness of 4 mm.




#### **ADJUSTABLE HOLDER**




Besides being able to adjust to the size of the table, the division of space or corner can be adjusted because the main holder is connected by a hinge system.




## Pin for connecting main holder (hinge system)





Then for the outer brace using a screw so that it can be used for tables of various thicknesses, a maximum of 40 mm.





#### **Dimension**

















# **ADJUSTABLE HOLDER**